

## CLEANING / MAINTENANCE AUTO SAFETY SHUT-OFF

### CLEANING/MAINTENANCE

- Always unplug the heater before cleaning and allow the heater to cool down.
- 1. Clean the unit with a soft cloth moistened with a mild soap and water solution.
- 2. NEVER use abrasive or flammable solvents to clean the unit.
- 3. After cleaning, be sure to completely dry the unit with a cloth or towel.
- 4. Store heater in a cool, dry location.
- 5. It is recommended that you store the unit in its original carton.

**TIP:** Over time, dust may accumulate on the front grills. This can be removed by wiping the unit with a damp cloth.

### AUTO SAFETY SHUT-OFF

This heater is equipped with a technologically-advanced safety system that requires the user to reset the heater if there is a potential overheating situation. When a potential overheating temperature is reached, the system will automatically shut the heater off. It can only resume operation when the user resets the unit.

#### If the heater shuts down and the Power Light Ring is flashing:

1. Stand the heater upright.
2. Unplug the heater and allow 30 minutes for the heater to cool down.
3. After 30 minutes plug the heater in and operate normally.
4. If the heater does not work normally, repeat steps 1, 2 and 3 again.

**NOTE:** If the heater is plugged in again and Power On/Off Button is pressed within the 30-minute cool down period, heater will run at Max Heat setting, but shut down in 2 seconds with the Power Light Ring flashing. Please repeat the above 4 steps to reset the heater again and ensure to allow sufficient time for the thermostat to cool down.

### FOR MODELS WITH TIP OVER PROTECTION

#### Tip Over Shut-Off:

When the unit is accidentally knocked over, it will instantly shut off and the Power Light Ring will flash. The unit may also shut off if it is moved or bumped. To reset, simply place the heater in an upright position, the Power Light Ring will stop flashing and it will operate normally.

**NOTE:** If unit does not turn on when placed in the upright position, press Power On/Off Button once and heater will resume operation.

### TROUBLESHOOTING

#### General Information:

Environmental Factors - There are a number of factors that will affect your desired comfort level. These factors can include insulation, open or drafty doors and windows, and outside temperature. Please check and take action if any of these potential problems are affecting your heaters ability to adequately warm your room.

Supplemental Heat - Portable electric heaters are intended for supplemental heating of rooms to heat the room your in and turn down the central heat thermostat. They are not intended to replace central heating systems.

**DO NOT attempt to repair or adjust any electrical or mechanical functions on this heater. Doing so will void warranty. The inside of the heater contains no user serviceable parts. All servicing should be performed by qualified personnel only.**

## NETTOYAGE/ENTRETIEN ARRÊT AUTOMATIQUE DE SÉCURITÉ

### NETTOYAGE/ENTRETIEN

Débranchez et laissez toujours refroidir le radiateur avant d'entreprendre son nettoyage.

1. Nettoyez l'appareil à l'aide d'un chiffon doux, humecté d'une solution de savon doux.
2. N'utilisez JAMAIS des produits abrasifs ou des solvants inflammables pour nettoyer l'appareil.
3. Après le nettoyage, séchez l'appareil avec un chiffon ou une serviette.
4. Rangez le radiateur dans un endroit frais et sec.
5. Le fabricant vous recommande d'entreposer l'appareil dans sa boîte d'origine.

**Conseil :** Après un certain temps, de la poussière peut s'accumuler sur les grilles avant. Vous pouvez enlever la poussière avec un chiffon humecté.

### ARRÊT AUTOMATIQUE DE SÉCURITÉ

Ce radiateur est doté d'un système de sécurité breveté et de technologie d'avant-garde. Ce système exige que l'utilisateur réinitialise le radiateur si une situation de surchauffe potentielle existe. Si le radiateur atteint une température de surchauffe potentielle, le système arrête automatiquement l'appareil. Il ne peut reprendre le fonctionnement qu'après la réinitialisation par l'utilisateur.

#### Le radiateur s'est éteint et la bague lumineuse d'alimentation clignote:

1. Remettez le radiateur d'aplomb.
2. Débranchez l'appareil et attendez 30 minutes jusqu'à ce que l'appareil soit refroidi.
3. Après les 30 minutes, branchez le radiateur et utilisez-le normalement.
4. Si le radiateur ne fonctionne pas normalement, répétez les instructions des paragraphes 1, 2 et 3.

**REMARQUE :** Si le radiateur est débranché et si la touche d'alimentation est pressée durant les 30 minutes de refroidissement, le radiateur chauffera à grande chaleur mais s'éteindra après 2 secondes et la bague lumineuse d'alimentation clignotera. Répétez les instructions des paragraphes de 1 à 4 pour réinitialiser le radiateur et laissez écouler un laps de temps suffisant afin que le thermostat refroidisse.

### MODÈLES À SÉCURITÉ ANTI-BASCULEMENT

#### MISE HORS DE SERVICE EN CAS DE REVERSEMENT:

Si l'appareil est renversé accidentellement, il s'arrête automatiquement et la bague lumineuse d'alimentation clignote. Il peut également s'éteindre s'il est déplacé ou heurté. Pour réinitialiser le radiateur, remettez-le d'aplomb et le fonctionnement normal reprendra.

**REMARQUE :** Si l'appareil ne se remet pas en marche après avoir été mis d'aplomb, pressez la touche d'alimentation une fois et le fonctionnement reprendra.

### DÉPANNAGE

#### Généralités

Conditions du milieu - Plusieurs facteurs affectent le niveau de confort désiré. Parmi ceux-ci, mentionnons l'isolation, les fenêtres et portes ouvertes ou mal soufflées ainsi que la température extérieure. Vérifiez si ces facteurs empêchent le radiateur de chauffer convenablement la pièce, et, le cas échéant, prenez les dispositions nécessaires pour les rectifier.

Choleur d'appoint - Les radiateurs électriques portatifs sont conçus pour réchauffer les pièces fraîches et vous aider à baisser le thermostat du chauffage central. Ils ne remplacent aucunement le chauffage central.

**N'essayer PAS de réparer ou d'ajuster une fonctionnalité électrique ou mécanique du radiateur sous peine d'annulation de la garantie. Le radiateur ne contient pas de pièces qui puisse réparer l'utilisateur. Contiez toujours les réparations au personnel compétent.**

## TROUBLESHOOTING

Troubleshooting for your Heater		
Trouble	Probable Cause	Solution
• Heater Does Not Turn On.	<ul style="list-style-type: none"> <li>Timer activated (only applicable on models with Timer feature).</li> <li>Tip-over switch engaged (only applicable on models with Tip-over protection).</li> <li>Manual user reset is activated.</li> <li>Not plugged in properly.</li> <li>Electrical outlet does not hold plug in securely.</li> <li>Thermostat set too low.</li> <li>Obstruction causing the heater not to operate.</li> <li>Circuit breaker trips.</li> </ul>	<ul style="list-style-type: none"> <li>✓ Press the Power Button to turn on the heater.</li> <li>✓ Set heater upright on a level surface.</li> <li>✓ Follow reset instructions listed in this manual.</li> <li>✓ Ensure plug is properly inserted. Make sure electrical outlet and circuit breaker are working.</li> <li>✓ Have outlet replaced by a licensed electrician.</li> <li>✓ Turn the Dial Knob clockwise to the highest temperature setting.</li> <li>✓ Unplug the heater and remove all obstructions. Position your heater 36 inches (0.9 m) away from all objects.</li> <li>✓ Make sure no other high wattage appliances are operating on the same circuit and reset breaker if needed.</li> </ul>
• Power Light Ring is Flashing or in some cases, Heater Turns On at Max setting but then Shuts Off in 2 seconds with Power Light Ring Flashing.	<ul style="list-style-type: none"> <li>Auto Safety Shut-off system is activated when there is potential overheating.</li> <li>Tip-over switch engaged (only applicable on models with Tip-over protection).</li> </ul>	<ul style="list-style-type: none"> <li>✓ Follow Auto Safety Shut-off instructions to reset the heater and allow sufficient time for the heater to cool down before plugging in again.</li> <li>✓ Set heater upright on a level surface.</li> </ul>
• Not Enough Heat.	<ul style="list-style-type: none"> <li>Heater is in Low or Fan Only setting.</li> <li>Thermostat set too low.</li> </ul>	<ul style="list-style-type: none"> <li>✓ Change setting to Max.</li> <li>✓ Turn the Dial Knob clockwise to the highest temperature setting.</li> </ul>
• Heater Cycles ON and OFF Frequently.	<ul style="list-style-type: none"> <li>The thermostat automatically turns the heater on and off to maintain selected comfort level.</li> <li>Every 10-15 minute the heater turns on and runs for a minute.</li> </ul>	<ul style="list-style-type: none"> <li>✓ To make this occur less frequently turn the Dial Knob clockwise to the highest setting.</li> <li>✓ This is normal operation to ensure the heater is maintaining the room temp accurately.</li> </ul>

## TROUBLESHOOTING

Troubleshooting for your Heater		
Trouble	Probable Cause	Solution
• Remote (if applicable) Does Not Work.	<ul style="list-style-type: none"> <li>Battery low.</li> <li>Distance too far.</li> <li>Control Panel Display dirty.</li> </ul>	<ul style="list-style-type: none"> <li>✓ Change battery (Description type, 3 volt, CR2025).</li> <li>✓ Remote works up to 20 feet (6m).</li> <li>✓ Be sure to point remote at control panel on heater and there are no obstructions.</li> <li>✓ Make sure display panel is clean.</li> </ul>
• Heater is Blowing Cold Air.	<ul style="list-style-type: none"> <li>When the heater is in Thermostat Mode and reaches the set temperature it will automatically perform a 15 second cool down (blowing cold air) to ensure thermostat accuracy.</li> <li>Unit is in the Fan Only setting.</li> <li>Power Button may have been pressed to turn off the heater.</li> </ul>	<ul style="list-style-type: none"> <li>✓ Raise the temperature higher or change setting to Low/Heat &amp; Save™ or Max.</li> <li>✓ Press the Max or Low/Heat &amp; Save™ Buttons.</li> <li>✓ Press the Power Button to turn on the heater.</li> </ul>
• Fan Speed Doesn't Change.	<ul style="list-style-type: none"> <li>Max and Low/Heat &amp; Save™ settings control the heat output of the heater and not the fan speed. Fan runs at the same speed on all settings.</li> </ul>	<ul style="list-style-type: none"> <li>✓ Run heater in Max for maximum heat output.</li> </ul>
• Unexpected Noise.	<ul style="list-style-type: none"> <li>You may hear a popping or crackling sound as the heater heats up. This is normal and safe operation. Once the heater heats up, the crackling sound will go away.</li> </ul>	<ul style="list-style-type: none"> <li>✓ If the noise persists call Sunbeam at 1-888-264-9669.</li> </ul>
• Unexpected Smell.	<ul style="list-style-type: none"> <li>There may be an odor or vapor coming from the heater the first time you use it or after prolonged or seasonal storage.</li> </ul>	<ul style="list-style-type: none"> <li>✓ This is normal and is the result of dust or other debris accumulating on the heating element. Make sure the heater is in a well ventilated area and continue running until the odor or vapor goes away.</li> </ul>

## WARRANTY INFORMATION

### 1 YEAR LIMITED WARRANTY

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions or in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty. This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use of improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized JCS service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

#### What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

JCS disclaims all other warranties, conditions representations, express, implied, statutory or otherwise.

JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profit, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

#### How to Obtain Warranty Service

##### In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-888-264-9669 and a convenient service center address will be provided to you.

##### In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-888-264-9669 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, located at 208 Hereford Street, Brampton, Ontario L6Y 0M1. If you have any other problem or claim in connection with this product, please write our Consumer Service Department. PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.

© 2009 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. Imported and distributed by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, 208 Hereford Street, Brampton, Ontario L6Y 0M1.

Printed In China

## Heater with Digital Thermostat

**Sunbeam™**



## Instruction Leaflet

### PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS

#### Radiateur à Thermostat Numérique

**Sunbeam™**



## Guide d'utilisation

### VEUILLEZ LIRE ET GARDER CES DIRECTIVES IMPORTANTES


## DÉPANNAGE

Dépannage du radiateur		
Problème	Cause Probable	Solution
• Le radiateur ne se met pas en marche.	<ul style="list-style-type: none"> <li>Minuterie en fonction (modèles à minuterie seulement).</li> <li>L'interrupteur de basculement est en fonction (modèles à sécurité anti-basculement seulement).</li> <li>La réinitialisation manuelle par l'utilisateur est activée.</li> <li>Le radiateur n'est pas correctement branché.</li> <li>La fiche ne s'assortit pas convenablement dans la prise.</li> <li>Le thermostat est réglé trop bas.</li> <li>Une obstruction empêche le radiateur de fonctionner.</li> <li>Le disjoncteur est déclenché.</li> </ul>	<ul style="list-style-type: none"> <li>✓ Pressez la touche d'alimentation pour allumer le radiateur.</li> <li>✓ Mettez le radiateur d'aplomb sur une surface plane.</li> <li>✓ Observez les instructions de réinitialisation données par l'utilisateur.</li> <li>✓ Assurez-vous que la fiche soit bien branchée et que la prise et le disjoncteur soient en bon état de marche.</li> <li>✓ Demandez à un électricien de remplacer la prise de courant.</li> <li>✓ Tournez le bouton du cadran en sens horaire pour le mettre au réglage le plus haut.</li> <li>✓ Débranchez le radiateur et retirez toute obstruction. Placez l'appareil à 36 (0,9 m) de tous articles.</li> <li>✓ Assurez-vous qu'aucun autre appareil de haute puissance ne soit branché sur le même circuit et réenclenchez le disjoncteur si nécessaire.</li> </ul>
• La bague lumineuse d'alimentation clignote ou part, le radiateur s'allume au réglage haut puis s'éteint après 2 secondes et la bague d'alimentation clignote.	<ul style="list-style-type: none"> <li>Le système d'arrêt automatique de sécurité est activé et il y a un risque de surchauffe.</li> <li>L'interrupteur de basculement est enclenché (modèles à sécurité anti-basculement seulement).</li> </ul>	<ul style="list-style-type: none"> <li>✓ Observez les instructions concernant l'arrêt automatique de sécurité pour réinitialiser le radiateur; avant de rebrancher l'appareil, laissez écouter un laps de temps suffisant pour le refroidissement.</li> <li>✓ Posez le radiateur d'aplomb sur une surface plane.</li> </ul>
• La bague d'alimentation clignote.	<ul style="list-style-type: none"> <li>Le</li></ul>	

## PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by the manufacturer may cause hazards.
2. To avoid fire or shock hazard, plug the appliance directly into a 120V AC outlet.
3. The heater is hot when in use. To avoid burns, DO NOT let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 ft (0.9 m) from the front of the heater and keep them away from the sides and rear.
4. DO NOT run cord under carpeting. DO NOT cover cord with throw rugs, runners, or the like. Arrange cord away from traffic area and where it will not be blocked.
5. This heater is not intended for use in bathrooms, laundry areas and similar indoor location. NEVER locate heater where it may fall into a bathtub or other water container.
6. Extreme caution is necessary when any heater is used by, or near children or invalids, and whenever the heater is left operating and unattended.
7. Always unplug the heater when not in use.
8. When unplugging, be sure to pull by the plug and not the cord.
9. DO NOT insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
10. DO NOT operate heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner. Return appliance to manufacturer for examination, electrical or mechanical adjustment, or repair.
11. A heater has hot and arcing or sparking parts inside. DO NOT use it in areas where gasoline, paint, or




THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

## VEUILZ LIRE ET CONSERVER CES DIRECTIVES DE SÉCURITÉ IMPORTANTES

Il faut toujours respecter les mesures de sécurité de base, y compris celles stipulées ci-dessous, en utilisant un appareil électrique afin de réduire le risque d'incendie, de chocs électriques et de blessures corporelles:

1. Lisez toutes les instructions avant d'utiliser l'appareil.
2. Afin d'éviter le risque d'incendie ou de chocs électriques, branchez l'appareil directement dans une prise électrique de 120 volts, c.a.
3. Le radiateur est chaud lorsqu'il est en marche. Pour éviter le risque de brûlures, NE touchez PAS aux surfaces chaudes avec la peau nue. Si elles sont froides, utilisez les poignées pour déplacer ce radiateur. Gardez les articles combustibles, tels que les meubles, oreillers, literies, papiers, vêtements et rideaux, à une distance d'au moins 3 pi (0,9 m) de la partie avant du radiateur et gardez également ces articles éloignés des côtés et de la partie arrière du radiateur.
4. NE placez PAS le cordon sous un tapis. Évitez de placer le cordon dans un endroit passant ou à un endroit où il risque de trébucher dessus.
5. Ce radiateur n'est pas conçu pour être utilisé dans une salle de bain, une salle de lavage ou tout endroit intérieur semblable. NE placez jamais le radiateur à un endroit où il peut tomber dans un baignoire ou autre contenant d'eau.
6. Observez les précautions supplémentaires d'usage si un radiateur est utilisé par ou à proximité des enfants ou par une personne handicapée et si le radiateur reste en marche sans surveillance.
7. Débranchez toujours le radiateur lorsqu'il n'est pas en usage.
8. Pour débrancher l'appareil, saisissez la fiche elle-même et non le cordon.
9. N'insérez PAS d'objets étrangers dans les ouvertures d'aération ou d'échappement puisque cela peut endommager le radiateur et risque de causer des chocs électriques ou un incendie.
10. N'utilisez PAS le radiateur si le cordon ou la fiche est



CET APPAREIL EST DOTÉ D'UN CORDON À FICHE POLARISÉE (une lame est plus large que l'autre). Afin de réduire les risques d'électrocution, cette fiche n'enfonce que dans un sens dans la prise électrique. Si la fiche ne s'insère pas dans la prise, retournez la fiche. Si elle ne s'adapte toujours pas, contactez un électricien qualifié afin d'installer la prise appropriée.

NE CONTOURNEZ PAS CE DISPOSITIF DE SÉCURITÉ ET N'ALTÉREZ LA FICHE EN AUCUNE FAÇON.

## ASSEMBLY INSTRUCTIONS

### TECHNICAL SPECIFICATIONS

- Amps: 12.5
- Wattage: 1500W (+5% -10%)
- Working voltage: 120V AC/60Hz

**NOTE:** Low heat setting may be 1000W on some models.

### ASSEMBLY INSTRUCTIONS

Unpack your heater from box, being careful to remove all parts from plastic bags and remaining packaging. Please save the carton for off-season storage.

Some models are packed with separate base and pedestal in the box. Carefully remove all parts from plastic bags. To prevent scratches, place all parts onto a cloth before assembly. Follow the below instructions for Pedestal/Base assembly:

**Pedestal Assembly** (if no pedestal is included in this model, move to Base Assembly)

Step 1: Run the power cord through the center of the assembled pedestal. Snap pedestal into the bottom of the heater housing. Refer to Figure 1, 2.

#### Base Assembly

Step 1: If the base is in two halves, snap them together by sliding slots of one base half into slots of second base half. Refer to Figure 3.

Step 2: Run the power cord through the center of the assembled base. To assemble the base to the unit (either one or two-piece base) first make sure the side marked "Rear" is facing the back of the heater. Line up holes of the base with holes on bottom of pedestal (or heater housing if no pedestal is included), and secure with 4 provided screws. Refer to Figure 4.

Step 3: Lace the power cord through the cord minders on the underside of the base. Refer to Figure 5.

Step 4: Turn the heater right side up on a flat level surface prior to beginning operation.

Figure 1




Figure 2




Figure 3




Figure 4





Figure 5



## PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

## INSTRUCTIONS D'ASSEMBLAGE

19. Arrêtez l'appareil et ne l'utilisez plus si la fiche ou la prise de courant est chaude. Nous recommandons de faire remplacer la prise de courant si la fiche ou la prise est chaude au toucher.

**VEUILZ LIRE ET CONSERVER CES CONSIGNES DE SÉCURITÉ IMPORTANTES**

### SPECIFICATIONS TECHNIQUES

- Ampères: 12.5
- Puissance: 1500 W (+5% -10%)
- Tension de service: 120 V CA/60 Hz

**REMARQUE:** Pour certains modèles, le réglage bas peut être de 1000 watts.

### INSTRUCTIONS D'ASSEMBLAGE

Sortez le radiateur de sa boîte d'emballage, en faisant bien attention de ne pas laisser de pièces dans les poches en plastique, ou autres. Gardez la boîte pour y ranger le radiateur hors saison. Pour certains modèles, le socle ou le pied peut être empaqueté séparément dans la boîte. Sortez soigneusement toutes les pièces des poches de plastique. Pour ne pas risquer de les rayer, placez toutes les pièces sur un lingé jusqu'à leur assemblage. Observez les instructions ci-après pour assembler le pied ou le socle:

**Assemblage du pied** (si le modèle n'a pas de pied, procédez à l'assemblage du socle)

Étape 1: Enfilez le cordon d'alimentation dans le pied assemblé. Enclenchez le pied dans la partie inférieure du boîtier du radiateur. Voir la figure 1, 2.

### Assemblage du socle

Étape 1: Si le socle est en deux parties, enclenchez celles-ci en glissant les fentes de l'une dans les fentes de l'autre. Voir la figure 3.

Étape 2: Passez le cordon d'alimentation au milieu du socle assemblé. Pour assembler le socle (qu'il se compose d'une ou de deux pièces) à l'appareil, commencez par vous assurer que l'appareil est conforme à la norme NMB-003 du Canada.

**Figure 1**




Figure 2





Figure 3



## FEATURES - OPERATIONS

### REMOTE CONTROL (IF APPLICABLE)

If your heater comes with a remote control, unpack the remote control from box. This includes one lithium battery, CR2025/3V. Please note this remote control will not work through walls. Remove battery before discarding the remote.

**NOTE:** REMOVE THE PROTECTIVE COVER FROM THE BATTERY PRIOR TO BEGINNING OPERATION.

### Battery Replacement

1. Locate the battery cover on the back of the remote control handset. Slide the battery cover out with your thumb.

2. Place battery into battery compartment.

3. Slide battery cover closed.

4. For your convenience, a remote control holder is integrated into the back of the heater housing.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### Mode Selection

Select your desired heat settings by pressing the corresponding buttons as located on your heater or press the Mode button on remote control (if applicable) to cycle through the heat settings. An indicator light will illuminate next to each button to indicate that the selected setting/mode is activated.

**NOTE:** Settings and control buttons may vary slightly between models.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### OPERATING INSTRUCTIONS

1. Place heater on a firm, level surface.
2. Plug heater into a standard outlet. Once plugged in, the Power Light Ring will illuminate.

**NOTE:** Avoid overloading your circuit by not using other high wattage appliances in the same outlet. At 1500 watts, this unit draws 12.5 Amps.

3. Operate heater by pressing the Power Button (○) and selecting modes and settings according to your preference.

**NOTE:** Remove the plastic film from the control panel before using (if included).

### Power On/Off

Press the Power On/Off Button to turn the heater on. Once on, the heater will run in the **Max Heat** mode and the **Stay On** temperature indicator light will remain illuminated.

2. Place battery into battery compartment.
3. Slide battery cover closed.
4. For your convenience, a remote control holder is integrated into the back of the heater housing.

**NOTE:** The Power Light Ring will remain illuminated while unit is plugged in.

### Mode Selection

Select your desired heat settings by pressing the corresponding buttons as located on your heater or press the Mode button on remote control (if applicable) to cycle through the heat settings. An indicator light will illuminate next to each button to indicate that the selected setting/mode is activated.

**NOTE:** Settings and control buttons may vary slightly between models.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES

- Remove the battery from the equipment when it is not being used for an extended period of time.
- Remove the used battery promptly.
- Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area.

This Class B digital apparatus complies with Canadian ICES-003.

### NOTES